# LanScaperPRO<sup>™</sup> NT800

# Network Tester Quick Start Guide



## **Essentials of Testing**

- A. LanScaperPRO will turn on to the last mode used before turn off. Press Quit (3) repeatedly to return to Main Menu.
- B. From Main Menu select Network Test Menu or Cable Test Menu using Navigation Keys (5) and then press the SEL Key (6)
- C. From Test Menu use Navigation Keys (5) to select desired test and then press the SEL Key (6)
- D. Press Test Key (8) to begin selected test

#### **Functions:**

- Network Testing Choose from one of five tests: Port Discovery, Ping Test, Hub Flash, Cisco Discovery, PoE Test
- **Cable Testing** Choose from one of four tests: Cable Test, Remote Mapping, Cable Length, Tone Generator
- Properties From Main Menu, select Properties to view the following: Last DHCP Values, MAC Address, Product Version, Charge Remaining.
- **Setup** From Main Menu, select Setup to Change Language, Calibrate Length, and Find Length Constant.
- Backlight Toggle the backlight on/off by pressing the Backlight Key (7)

#### **Features:**

- Port Discovery detects and reports configuration of Ethernet devices. Also identifies many other possible connections found on RJ45 jacks.
- Ping Tests of IP devices using DHCP or Static host configuration
- Hub Flash to locate a hub or router port
- Cisco Discovery to detect and display CDP messages broadcast over the network.
- Power over Ethernet tests to detect, identify, display pins used, as well as Voltage and current provided by PoE devices.
- Cable Tests can be done single ended (shorts, opens, split pairs) or with included remote (full wire map)
- Remote Mapping identifies up to 8 full test remotes or up to 20 ID-only remotes
- Cable Length measurement in feet or meters using user-defined cable capacitance.
- Tone Generator generates selectable tones on selected pins for use with tone tracers.

For more information or technical help, visit www.jdsu.com/know



### **Button Functions**

- 1. RJ45 Test Port
- 2. Indicator LEDs (Link, 100Mbps, Low Battery)
- 3. Quit Key
- 4. Accept Key
- 5. Navigation Keys
- 6. SEL (Select) Key
- 7. Backlight Key
- 8. Test Key
- 9. Power Key

KnowtheNetwork. Product specifications and descriptions in this document subject to change without notice. © 2008 JDS Uniphase Corporation