

# INX Battery Door with Insert Installation

Figure 1-1: INX Battery Door with Insert and Optional Locking Screw



Socket Head Screw, M2x0.4mm Thread  
8 mm Long  
\* Not included

## Installation

<p>Step 1 Power off the microscope, and rotate the battery door counterclockwise to remove it.</p>	
<p>Step 2 Mount the battery door with insert onto the microscope, and rotate it clockwise to secure it.</p>	
<p>Step 3 Optionally, insert the locking screw into the lock screw hold to lock the battery door in place.</p>	
<p>Step 4 Optionally, route the lanyard through the slot.</p>	